



Satellite station, SR 25-2

Art.-Nr.: 7.002.05

Satellite station, SR 25-2**Satellite stations enabling execution of all sanitary operations.**

SR 25 satellite station connected to water unitenables execution of the following operations:

rinsing, foam application, disinfection.

SR 25 station is connected to compressed air network and to the pressunized water supply piping. The station is provided with dosing unit for precise setting of working solution concentration. There are several types of satellite stations, i.e.:

Technichal data:

Injektor system:	single system with dosage, independent system for the detergent
weigth:	6,6 kg
weigth:	6,2 kg
Min. water pressure on entrance:	12 bar
Max. water pressure on exit:	30 bar
Max temp on entrance:	70 °C
Min. air pressure on entrance:	4 bar
Max. air pressure on exit:	10 bar
Min.air demand	150 l/min
Water use by lather:	6-8 l/min
Max length of pipe:	25 m
detergent:	0,2 - 10 %
dimensions:	290 x 320 x 180 mm